

How to maintain Affinity Sports Pro or Affinity Powerlift

Should the couch start to make a noise when lowering or raising, slightly loosen off the bolts a fraction in the yellow circles and apply lubricant such as WD40.

This little black screw can also be slightly loosened. It is in 4 locations.

