






BULB REPLACEMENT INSTRUCTIONS PU8

<p>① Switch 'OFF' at mains</p>		
<p>②</p> <p>UNDER NO CIRCUMSTANCES USE THE OLD 'O' RING</p> <hr/> <p>DO NOT GET THE OLD & NEW 'O' RING MIXED UP !</p>	<p>③ CORRECT</p>  <p>Check before & during assembly that the 'O' ring is properly in its seating</p>	<p>④ WRONG</p>  <p>Do NOT use lubricants on 'O' ring</p>
<p>⑤ PU8 BULB 300 Watt 12 Volt</p>  <p>Ensure contacts are clean with emery cloth provided and screws are securely tightened before replacing bulb into light housing.</p>	<p>⑥ Check 'O' ring seating AGAIN</p>  <p>Tighten screws in a cross pattern sequence</p> 	
<p>ALWAYS ASK FOR Certikin PRODUCTS and 'spare' a thought for the future</p>		